



Housewrap

www.AlphaProTech.com

REX™ Wrap is a woven and coated polypropylene weather resistant barrier that provides air and moisture protection.

- Tiny micro perforations allow moisture vapor inside the wall cavity to escape, and prevents moisture condensation
- Light weight and easy to install
- Tear resistance reduces jobsite waste
- Meets or exceeds all building codes
- Custom print available at no additional cost (one pallet minimum)
- Nationwide Distribution

	Product Specification	Test Method
Composition	Woven Polypropylene	
Weight Per Roll	11.8 lbs/ MSF	
Thickness	5.5 mils	
Tensile Strength		ASTM D-882
MD	45.17	
CD	50.77	
Tear Strength		ASTM D-5034
MD	34.13	
CD	36.53	
Water Resistance	Pass	ASTM D-1709
MVTR/Perms	8 Perms	ASTM E-96
Fire Rating	Class A	ASTM E-94

Roll Size	Rolls per Pallet
9 ft x 100 ft	50
9 ft x 150 ft	45
9 ft x 195 ft	40
10 ft x 100 ft	50
10 ft x 150 ft	45
10 ft x 195 ft	40
54 in x 100 ft	100
54 in x 150 ft	90
54 in x 195 ft	80
36 in x 100 ft	150
36 in x 150 ft	135
36 in x 195 ft	120

Alpha ProTech Engineered Products Inc.
 301 South Blanchard St.
 Valdosta, GA 31601
 866-312-1837

Nationwide Distributions Centers
 Valdosta, Georgia
 Janesville, Wisconsin
 Nogales, Arizona
 Salt Lake City, Utah



Installation Instructions

www.AlphaProTech.com

1. Begin by aligning the bottom edge of the roll with the base of the wall, approximately 6" (152 mm) from a corner, folding several inches of the material under itself and fasten securely to a framing member. Be sure that the installation is horizontal on the vertical wall.
2. Unroll REX™ Wrap with the printed side out, wrapping the entire building including door and window openings. Plastic cap nails or staples with a minimum 1" (25 mm) crown may be used. Fasteners shall be spaced a maximum of 16" (406 mm) on center along studs and 8" (203 mm) on center along top and bottom sill plates. When installing REX™ Wrap over non-structural sheathing products or foam insulation boards, fasteners must penetrate the framing members no less than 1/2" (13 mm) and spaced as noted above.
3. Cut through REX™ Wrap using a modified "I" pattern at door and window openings. Fold excess material inside the rough openings and fasten securely through the layers to a framing member.
4. If door frames and windows are already installed, trim REX™ Wrap as close as possible and tape using contractor tape to seal seams around openings.
5. For vertical laps, fold the edge of REX™ Wrap under and attach to the structural sheathing or framing member. The seams must be overlapped a minimum of 6" (152 mm) unless otherwise specified.
6. A minimum 2" (51 mm) overlap should be used for all horizontal laps.
7. All vertical and horizontal laps should be taped using contractor tape. Final wall covering should be installed within 6 months of the installation of REX™ Wrap .

Alpha ProTech Engineered Products Inc.
301 South Blanchard St.
Valdosta, GA 31601
866-312-1837

Nationwide Distributions Centers
Valdosta, Georgia
Janesville, Wisconsin
Nogales, Arizona
Salt Lake City, Utah